

BRUKSANVISNING USER INSTRUCTIONS GEBRAUCHSANWEISUNGEN KÄYTTÖOHJEET

CORE PLUG REMOVAL TOOL(Plug-ut)

24/26 p/n 1769016, 27/29 p/n 1769015, 30/33 p/n 1769011,
34/37 p/n 1769012, 38/42 p/n 1769013, 45 p/n 1769014



SVENSKA

ENGLISH

DEUTSCH

SUOMI

